

Easy DIY bath bombs

Supplies

- 1 cup baking soda
- 1/2 cup citric acid
- 2 tablespoons epsom salts
- 3 tablespoons coconut oil melted
- 4 drops essential oil
- 1 teaspoon water or more if necessary

molds or large ice cream scoop



Instructions

1. combine baking soda, citric acid, and epsom salts. stir well.
2. in a smaller bowl combine coconut oil and essential oils
3. slowly whisk in wet ingredients into dry. it should reach a crumbly consistency.
4. your mixture is ready when you can mold it into a shape and it sticks without coming apart. if it is too crumbly, add in water, 1 tsp at a time. mixture should be dry but able to hold a shape.
5. pack them into your molds or a large ice cream scoop .
6. dry for about 8-12 hours.
7. enjoy in your bath!

@nestingwell